

SLEEKSTERTM

FRAME MOUNTED LIGHT BARS

By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923

INSTALLATION INSTRUCTIONS

Part # 3015 ('94-'02 Dodge 2500/3500)



Supplied hardware:

- 1/2" x 1" bolt (2)
- 1/2" x 1 1/2" bolt (2)
- 1/2" lock washer (4)
- 1/2" nut (4)

1. Your new Sleekster light bar will mount to the frame using two of the holes below the forward most body mount.
2. Remove the rearward most bumper bracket bolt located under the body mount on each side.
3. Hold the light bar in position with the bracket between the body mount.
4. Start the 1/2" x 1" (short) bolt in the rearward hole of the light bar and through the frame on each side of the truck.
5. Reaching up inside the frame start the 1/2" lock washer and nut being careful not to drop the lock washer or nut inside the frame.
6. Start the 1/2" x 1 1/2" (long) bolt through the forward hole of the light bar, frame, and bumper bracket.
7. Loosely install the 1/2" lock washer and nut on the two remaining bolts.
8. Align the light bar so the light tabs are level with the truck and the bar is square with the bumper.
9. Tighten all hardware.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

Randy Ellis Design, Inc.

2855 W. Fairmount Ave., Phoenix, AZ 85017

Phone: 602-803-1122

Web: www.randyellisdesign.com

E-mail: info@randyellisdesign.com