

# **SLEEKSTER™**

**FRAME MOUNTED LIGHT BARS**  
*By Randy Ellis Design Inc.*



## INSTALLATION INSTRUCTIONS Part # 4005 ('02-'07 GM 2500/3500 4 tab)

Supplied hardware:  
M12 1.75 x 35 mm (2)  
M12 flat washer (2)

1. Locate the front tow hooks and their mounting bolts.
2. Remove the lower and inside bolts from the tow hooks.
3. Place the light bar through the tow hook openings in the valance panel.
4. Start the lower bolts through the light bar brackets and into the tow hooks.  
*NOTE: Do not tighten at this time.*
5. Start the supplied M12 1.75 x 35 mm bolts through the inside holes of the bracket and into the tow hooks.
6. Tighten all bolts.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

**Randy Ellis Design, Inc.**  
2855 W. Fairmount Ave., Phoenix, AZ 85017  
Phone: 602-803-1122  
Web: [www.randyellisdesign.com](http://www.randyellisdesign.com)  
E-mail: [info@randyellisdesign.com](mailto:info@randyellisdesign.com)