

SLEEKSTERTM

FRAME MOUNTED LIGHT BARS
By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923

INSTALLATION INSTRUCTIONS **Part # 5005 ('95.5-'04 Tacoma)**



1. Remove import hooks and/or tow hooks from bottom of frame.
2. Hold light bar into position with mounting brackets against the frame and lined up with the holes from the tow hooks.
3. Re-install import hooks and/or tow hooks hand tight with the light bar mounting brackets sandwiched between the frame and tow hooks using factory hardware.
4. Align light bar side to side until centered.
5. Tighten all hardware.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

Randy Ellis Design, Inc.
2855 W. Fairmount Ave., Phoenix, AZ 85017
Phone: 602-803-1122
Web: www.randyellisdesign.com
E-mail: info@randyellisdesign.com