

# ***SLEEKSTER***<sup>TM</sup>

## **FRAME MOUNTED LIGHT BARS**

*By Randy Ellis Design Inc.*

U.S. DESIGN PATENT NO. D521,923

### **INSTALLATION INSTRUCTIONS**

#### **Part # 5105 ('04-'06 Tundra)**



**Due to varying bumper alignment from the factory, some of the Tundra's bumpers may interfere with the center light tab of the light bar. To remedy this, we have added a spacer that may need to be installed under the forward bolt. This spacer will be installed between the light bar bracket and frame on the forward left and right bolts only. This spacer will tilt the light bar forward slightly to gain the needed clearance.**

1. Remove import tie down and tow hook from bottom of frame.
2. Hold light bar into position with mounting brackets against the frame and lined up with the holes from the tow hook/ import tie down.
3. Re-install tow hook on opposite side of frame hand tight with the light bar mounting brackets sandwiched between the frame and tow hook using factory hardware.
4. Discard factory import tie down and re-use bolts to mount the other side of the light bar, hand tighten bolts.
5. Align light bar side to side until centered.
6. Tighten all hardware.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

***Randy Ellis Design, Inc.***

2855 W. Fairmount Ave., Phoenix, AZ 85017

Phone: 602-803-1122

Web: [www.randyellisdesign.com](http://www.randyellisdesign.com)

E-mail: [info@randyellisdesign.com](mailto:info@randyellisdesign.com)