

SLEEKSTER™

FRAME MOUNTED LIGHT BARS

By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923

INSTALLATION INSTRUCTIONS

Part # 5305 ('05-'10 FJ)



Supplied hardware:
M12 1.25 x 70 mm bolt (2)
M12 lock washer (2)
Spacer (2)

1. Locate the 3 studs on the front of each frame rail, behind the bumper cover.
NOTE: These are the 3 studs pointing forward towards the outside.
2. Remove the nuts from each of the 3 studs.
NOTE: Do not discard the nuts as they will be reused.
3. Position the light bar brackets over the 3 studs on each side that you remove the nuts from.
4. Loosely install the upper nut on the left and right studs on the front of the frame rails.
5. Locate the hole towards the rear of each light bar bracket.
6. Place the supplied spacer between the light bar bracket and the frame, lined up with the rearward hole in each light bar bracket.
7. Insert and start the supplied bolt with lock washer through the light bar bracket, the spacer, and into the threaded hole of the frame.
NOTE: Do not tighten the bolts at this time.
8. Install the remaining nuts and tighten the nuts on the 3 studs on each side of the frame.
9. Tighten the supplied M12 bolts into the frame.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

Randy Ellis Design, Inc.
2855 W. Fairmount Ave., Phoenix, AZ 85017
Phone: 602-803-1122
Web: www.randyellisdesign.com
E-mail: info@randyellisdesign.com