

SLEEKSTER™

FRAME MOUNTED LIGHT BARS

By Randy Ellis Design Inc.



INSTALLATION INSTRUCTIONS

Part # 6005 ('03-'10 H2)

Supplied hardware:
M10 1.50 x 30 mm bolt (4)
M10 flat washer (4)

1. Remove the plastic filler panel under the grille.
2. If your truck has the factory grille guard, skip to step 8.
3. Notice the hood hinges and their empty threaded bolt holes; this is where the light bar attaches.
4. Position the light bar to line up with the empty threaded holes.
5. Start the supplied M10 1.50 x 30 mm bolts through the light bar brackets and into the hood hinges.
6. Tighten the 4 bolts.
7. "Pop" the plastic filler panel back into place.
8. If your truck has a factory grille guard: Hold the grille guard in place and remove the 4 bolts attaching it to the hood hinges.
9. Position your new light bar so the brackets are on top of the grille guard brackets.
10. Start the 4 factory bolts through the light bar brackets, grille guard brackets and into the hood hinges.
11. Tighten the 4 bolts.
12. "Pop" the plastic filler panel back into place.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

Randy Ellis Design, Inc.
2855 W. Fairmount Ave., Phoenix, AZ 85017
Phone: 602-803-1122
Web: www.randyellisdesign.com
E-mail: info@randyellisdesign.com