

# **SLEEKSTER™**

## **FRAME MOUNTED LIGHT BARS**

*By Randy Ellis Design Inc.*

U.S. DESIGN PATENT NO. D521,923

### **INSTALLATION INSTRUCTIONS**

#### **Part # 6405 (Rhino)**



Supplied hardware:  
3/8" X 2" grade 8 bolt (4)  
Grade 8 SAE flat washer (8)  
3/8" Stover C lock nut (4)

Tools needed:  
14 mm and 9/16" -- 3/8" drive socket and extension with ratchet  
14 mm and 9/16" wrench

1. Remove the four forward cage mount bolts using the 14 mm socket and wrench.  
*NOTE: These nuts and bolts will be replaced with the supplied grade 8 hardware.*
2. Place the light bar so the holes in the brackets correspond with the cage mount holes.
3. Place one washer on each of the supplied 3/8" grade 8 bolts.
4. Start each bolt through the light bar bracket then through the cage mounts.
5. Place one supplied washer and nut on each of the bolts and tighten using the 9/16" socket and wrench.  
*NOTE: The supplied nuts are a locking type nut, the nut should start by hand and thread on the bolt a few turns before needing tools to finish tightening.*



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from  
Randy Ellis Design, Inc.

**Randy Ellis Design, Inc.**  
2855 W. Fairmount Ave., Phoenix, AZ 85017  
Phone: 602-803-1122  
Web: [www.randyellisdesign.com](http://www.randyellisdesign.com)  
E-mail: [info@randyellisdesign.com](mailto:info@randyellisdesign.com)