

SLEEKSTER™

FRAME MOUNTED LIGHT BARS

By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923

INSTALLATION INSTRUCTIONS

Part # 6505 ('04-'10 Titan)



Tools needed:
17 mm ½" drive socket
½" drive extension
½" drive ratchet
17 mm wrench

Tools needed if equipped with factory skid plate:
#T-50 torx bit
10 mm wrench or socket and drive

1. If your truck is equipped with the factory skid plate, remove the skid plate.
2. Remove the tow hooks (and skid plate mounts if your truck was equipped with the factory skid plate).
NOTE: Set them aside in the same orientation as they came off, they will be remounted in the factory location.
3. Hold the light bar in place with the brackets against the frame and the light bar bracket hole aligned with the forward tow hook bolthole.
4. Place both factory bolts in the tow hook (and skid plate mounts if equipped).
5. Roll hooks (and skid plate mounts if equipped) with bolts into place and start bolts into frame.
NOTE: Bolts must be inserted in tow hooks and skid plate brackets before rolling hooks/ brackets into place.
6. Tighten forward most bolts first, and then tighten rear bolts.
7. Reinstall factory skid plate if equipped.



Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

Randy Ellis Design, Inc.
2855 W. Fairmount Ave., Phoenix, AZ 85017
Phone: 602-803-1122
Web: www.randyellisdesign.com
E-mail: info@randyellisdesign.com