

SLEEKSTERTM
FRAME MOUNTED LIGHT BARS
By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923

INSTALLATION INSTRUCTIONS
Part # 3705 ('07-'11 GM 1500 2 tab)



1. Your new light bar will use the factory OEM tow hook bolts while retaining the factory tow hooks.
2. Remove the front and rear tow hook bolts from the passenger side tow hook.
3. Remove the front bolt from the driver side tow hook.
4. Slide the light bar brackets through the outsides of the tow hook openings of the valance panel.
5. Align the holes in the light bar brackets with the tow hook holes and insert the forward bolts on driver and passenger side, then start the nuts by hand.
6. Insert the rear bolt in the passenger side tow hook and start it by hand.
7. Hold the light bar bracket up against the bottom of the frame on driver and passenger side then tighten all hardware.

Install the lights of your choice and enjoy!

Thank you for purchasing quality products from Randy Ellis Design, Inc.

Randy Ellis Design, Inc.
2855 W. Fairmount Ave., Phoenix, AZ 85017
Phone: 602-803-1122
Web: www.randyellisdesign.com
E-mail: info@randyellisdesign.com